





## Bruksanvisning


SE

Sängvibratorn kan du använda tillsammans med din Visitladdare eller Visitmottagare. Den väcker dig med vibrationer under madrassen eller huvudkudden.

#### Gör så här

- 1 Anslut sängvibratorn genom att sätta i kontakten i sängvibratoruttaget på laddaren eller mottagaren (se nedan).
- 2 Tryck på testknappen på någon av de sändare du har till Visitsystemet och kontrollera att sängvibratorn vibrerar.

**Obs!** När du ansluter sängvibratorn till pagerladdaren måste pagern sitta i laddaren för att sängvibratorn ska fungera.



### Technical information



**Operating voltage** 2.0 - 4.0 V DC from a Visit receiver or charger

Power consumption 250 - 750 mA

**Dimensions** 88 x 88 x 27 mm (w x h x d)

Weight 120 g

Colour White with red rubber anti-skid protector

Cable length 2 meters

Function The BE1270 Bed shaker is a vibrator for indoor use

that is placed in the bed to attract the attention of

the user with vibrations.

**Installation** The bed shaker is usually placed under a pillow or

under the mattress. It is connected to a range of Bellman & Symfon products with vibrator outputs.

**Testing** Connect the bed shaker to a Visit receiver or charger

with vibrator output and follow the testing procedure. **Usage and storage**For indoor use only, Temperature during transport

and storage:  $-10^\circ$  to  $50^\circ$  C,  $14^\circ$  to  $122^\circ$  F. Temperature during operation:  $0^\circ$  to  $35^\circ$  C,  $32^\circ$  to  $95^\circ$  F

Relative humidity: 15% -90% (non condensing).

Care and cleaning Maintenance free. Clean with a soft cloth. Do not use

cleaners, solvents, ammonia or alcohol. Not reusable.

# Troubleshooting

If	Try this
The bed shaker does not vibrate	Check that the plug is connected correctly.     Check that the receiver is picking up signals.

## **FCC** compliance statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## **Industry Canada statement**

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L' appareil ne doit pas produire de brouillage;
- (2) L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.





### Manufacturer

Bellman & Symfon Group AB Södra Långebergsgatan 30 436 32 Askim Sweden Phone +46 31 68 28 20 E-mail info@bellman.com bellman.com



Revision: BE1270\_020MAN005

Date of issue: 2020-10-28

TM and © 2020 Bellman & Symfon AB. All rights reserved.